




Instruction Manual



AGE 3+

TAKARA TOMY

WARNING:
CHOKING HAZARD: Small parts
Not for children under 3 years

Layout size: approx. 620(W) × 400(H) × 480(D) mm

REQUIRES 2 LR14 ("C" SIZE) BATTERIES
(NOT INCLUDED).

Grand Mall TOMICA Building

Products not included in the set are sold separately.

※Photos are for illustrative purposes only. Actual product may differ slightly. Your understanding is appreciated.

Thank you for purchasing TAKARATOMY's [Grand Mall TOMICA Building].
Please read the "Instruction Manual (this paper)" before use.
Also, be sure to keep this manual after reading it.



くちにいれない



うえにのらない

Warning

Parents and guardians are asked to thoroughly read through the following.

● This product includes small components and parts. Children under the age of 3 must not be allowed to use this product, as doing so risks accidental ingestion and suffocation.

Caution

● Do not climb up, lean on, or hold on to the assembled product. ● Misuse of batteries may cause them to overheat, explode, or leak. Please take note: Do not use rechargeable batteries. ● Do not mix old and new batteries or different types of batteries. ● Please insert batteries in the poles (+)(-) (plus/minus) correctly. ● After playing, be sure to turn off the switch and remove the batteries. ● Do not short-circuit, generate electricity, disassemble, heat up, or put them in fire. ● If the liquid from the battery is leaking and gets into your eyes, immediately wash them with plenty of water and consult a doctor. If it gets on your clothes or clothes, wash it with water. ● For the product disposal, please follow your local government's waste disposal instructions. ● Please avoid getting your body parts (e.g. fingers, hair, etc.) caught in moving elevator. Doing so can cause injury. ● Do not insert your fingers into the gaps in between the moving parts. Doing so can cause injury. ● Do not place plastic bags over your head or cover your face with them. Doing so can lead to suffocation. ● After using this product, please store in a location out of the reach of children under the age of three to avoid unexpected accidents.


<Important notes> ○ Before using this product, be sure to thoroughly read the Instruction Manual. ○ Do not pull or bend movable parts or mounting sections in inappropriate directions. ○ Foreign objects such as food debris, dust, or dirt entering the elevator or main unit may cause malfunction or damage. ○ Do not hit or drop the product. Do not transport the product fully assembled or loaded with TOMICA. ○ Play on a flat surface. Use only TOMICA to play with this product. ○ Please note that you may not be able to properly play with some models of TOMICA (heavy or lightweight, tall, wide, narrow, special, etc.). ○ The product cannot be used with TOMICA Beam, LONG TOMICA, TOMICA Hyper Series, Dream TOMICA, Thomas TOMICA, tomica PREMIUM, Cars TOMICA, Disney Motors, or Vehicles TOMICA. ○ Please be aware that some conditions of product usage may result in damage to floors and other surfaces and/or TOMICA coating peeling. ○ Please immediately discard packaging after opening it.

Precautions and Notes on TOMICA Driving



If something is wrong with your TOMICA, perform the following maintenance.
※Depending on the condition of the TOMICA, it may not be repairable.

1. Perform maintenance on the TOMICA

1 Gently press down on TOMICA's wheels from both sides with your fingers and wipe off debris on the surface of the wheels with a soft cloth. Remove dust between the axle and chassis of the TOMICA with a brush or an old toothbrush.




2 Spray commercially-available water-based wax on a cotton swab, soak it in thoroughly, and apply it to the axle portion in the center of the wheel of the TOMICA.




2. Perform maintenance on the road

Polish the running surface and sidewalls of the road as shown on the right figure. For polishing, use commercially-available water-based wax or polish protectant.



※ Please read the instruction manual for water-based wax or polish protectant carefully for detailed instructions.



The following TOMICA cannot be played with this product.



Wide-body vehicles



High vehicles with central centrifuge which are prone to tip over in the slope



Vehicles with coupling section



Non four-wheeled vehicles



Vehicles with cargos, that are prone to get stuck in the course

Manufactured by TOMY Asia Ltd. under license from TOMY Company, Ltd.

TOMY ASIA LIMITED

Nos. 809B-12 & 15, 8th Floor, Exchange Tower,
No.33 Wang Chiu Road, Kowloon Bay,
Kowloon, Hong Kong.



Homepage



Youtube channel


© TOMY

Set components · How to apply stickers


Please check the set components in the package.
Referring to the package photo,
affix the stickers according to the circled number (○).




Toyota ALPHARD ×1




Rooftop Heliport ×1



Base Unit ×1



West Mall Parking Lot 2F ×1




Elevator Unit ×1




West Mall Parking Lot 3F ×1



West Mall Parking Lot 4F ×1



East Mall Rooftop Parking Lot ×1




Ramp A ×1




Ramp B ×1



Ramp C ×1



Pillar 1 ×1



Align the two notches on the sticker with the two-line positions shown in the figure and affix it.



Pillar 2 ×1



Pillar 3 ×1




Fueling Nozzle ×1



Pillar 4 ×1



Pillar 5 ×1



Pillar 6 ×1



West gate ×1



East gate ×1




TOMICA Twin Course Mountain Drive Connection Gate ×1



TOMICA 2-WAY Action Expressway Connection Gate ×1



Entrance / Exit Gate ×1




Stickers ×1

Instruction ×1

How to play with other Playsets

Let's connect the three worlds!
TOMICA goes back and forth to various courses!


Easy Connection!
No additional parts needed!



How to connect with "TOMICA Twin Course Mountain Drive (sold separately)"

Place this product and the "TOMICA Twin Course Mountain Drive (sold separately)" Close together as shown in the photo.


Let's get these two gates closer together



TOMICA Twin Course Mountain Drive (sold separately)

This product


1 Open the gate part of the product and the gate part of "TOMICA Twin Course Mountain Drive (sold separately)",
2 Connect the roads by placing the rightmost connecting section of "TOMICA Twin Course Mountain Drive (sold separately)" from above and inserting it firmly.



How to connect with "TOMICA 2-WAY Action Expressway (sold separately)"

Place this product and "TOMICA 2-WAY Action Expressway (sold separately)" close together as shown in the picture.


Let's get these two gates closer together



This product


TOMICA 2-WAY Action Expressway (sold separately)

1 Open the gate part of the product and the gate part of "TOMICA 2-WAY Action Expressway (sold separately)",
2 Connect the roads by placing the rightmost connecting section of "TOMICA 2-WAY Action Expressway (sold separately)" from above and inserting it firmly.



How to assemble and insert batteries


1 Set the batteries first




Caution For safety reasons, even if the main switch is turned ON, the product will not operate unless the elevator unit is set.

※Be sure to remove or replace the batteries only in the Base Unit.


3 Attach each part to Ramp A




2 Install the elevator unit




4 Attach Ramp A to the Base Unit




5 Attach the East Mall Rooftop Parking Lot to the main unit




6 Attach the Fueling Nozzle to the Pillar 2, set the Pillar 2 and Pillar 3 in the West Mall Rooftop Parking Lot 2F, and attach the assembly to the main unit




7 Attach the Ramp C at the position shown below




8 Set the Pillar 4 and Pillar 5, and attach the West Mall Rooftop Parking Lot 3F and the West Gate



9 Set the TOMICA Twin Course Mountain Drive Connection Gate at the West Mall Rooftop Parking Lot 4F and attach the assembly at the position shown below




10 Complete!




How to Play


1 You can play either automatically or manually



3 Turn the main switch ON!




5 Move TOMICA to the front of the elevator!




2 If TOMICA is stuck in the elevator





4 Let's enter TOMICA from the entrance/exit of the Grand Mall TOMICA Building!



6 TOMICA is running up the spiral elevator!



7 West Mall Multilevel Parking Lot Course! East Mall Rooftop Parking Lot Course! Which Course Do You Prefer?



8 Park TOMICA on the West Mall Multilevel Parking Lot!



9 Open the gate and start out TOMICA at once!



8 Park TOMICA on the East Mall Rooftop Parking Lot!



9 Open the gate and start out TOMICA at once!




10 Move TOMICA to the front of the elevator and play again!




Caution Depending on the model and combination of TOMICA at the elevator entrance, each course, and curves, the car may overturn, ride back and forth, or go off course when running at high speed. In such cases, change the combination of models of TOMICA or adjust the number of TOMICA to be run to reduce jamming of the cars.

When playing with the Grand Mall TOMICA Building, please note the following:

- At the spiral elevator entrance, merging points of left/right courses, and curves, depending on the types or combinations of TOMICA, if they are moving at high speed, they may flip over, ride over each other, or derail from the course. Therefore, please change the arrangement of the TOMICA, or adjust the number of TOMICA on the course to reduce jams.





If you use a single-height TOMICA, it tends to bounce or wobble up and down.



Some TOMICA may climb onto another lower-height TOMICA on the course.



- If your TOMICA gets stuck on the Spiral Elevator or West mall, try moving them by hand or using fewer TOMICA at a time!



- An excess use of TOMICA may prevent the stopper from lowering. If this happens, please reduce the number of TOMICA on the course.

