



にぎやか4アクション!

TOMICA DIY ACTION!

ドミカ整備基地ボックス

MAINTENANCE BASE BOX

TAKARA TOMY

Instruction Manual



*Tomica (mini car) is not included

REQUIRES 2 LR6 ("AA" SIZE) BATTERIES (NOT INCLUDED).

Box Dimension [approx.]
268(W) x 240(H) x 106(D) mm

Unfolded Dimension [approx.]
370(W) x 290(H) x 315(D) mm

WARNING

To parents, please be sure to read the following.

● There are small parts with this toy. Do not give them to children under age 3 to avoid accidental swallowing/suffocation.

CAUTION

● Be careful not to catch fingers, hair or clothes in the rotating part of the Electrical Screwdriver. ● If misused, batteries could overheat, burst, or cause fluid leakage. Please note the following: Never use secondary batteries (rechargeable batteries). Do not use old and new batteries together, and do not use different kinds of batteries in combination. Place batteries in the proper direction (negative and positive). Switch it off after use, and take out the batteries. Do not short circuit, dismantle, or heat batteries, or throw them into fire. If the fluid from the battery gets into the eye, wash it with running water and consult with a doctor. Wash with running water if the fluid from the battery has contacted the skin or clothing. When disposing of waste batteries, follow the waste disposal regulations of the local government. ● Do not step on the main body, as that could cause an accident. ● Be careful not trap your fingers, hair, clothes, etc. in moving parts. ● Do not play with the product in a violent manner, such as bumping or shaking it. ● Do not cover the head or face with plastic bag. There is a risk of suffocation. ● There is a risk of unexpected accident. After using it, please keep it out of reach of children under age 3.

Set Content

※Below photos shown the scene with stickers affixed.

■ Electric Screwdriver main body × 1
■ Elevator Floor × 1

■ Bit × 1
■ Slope × 1

■ Box Body × 1

■ English Manual × 1

■ Handle × 1


■ Sticker × 1

<IMPORTANT NOTES>

- Thoroughly read the information on all sides of the package and manual.
- Do not pull or bend movable parts or mounting sections in inappropriate directions.
- Play on a flat surface.
- Do not carry the product after assembled or with Tomica cars loaded.
- Do not use minicars other than Tomica.
- Please note that this product is not compatible with some types of Tomica (tall cars, heavy or light cars, narrow cars, special cars, etc.).
- Tomica 4D, Long Tomica, Tomica Hyper Series, Dream Tomica, Thomas Tomica, Tomica Premium, CARS Tomica, Disney Motors, Tomica Star Wars, and Toy Story Tomica cannot be used.
- Depending on the situation in which the product is used, the floor could be damaged, or the coating of the Tomica could be peeled off.
- Please dispose of packing material after opening it.

How to affix stickers

Affix stickers by referencing below product image and sticker number.



Closed




Electric Screwdriver

How to insert battery

① Use a Phillips-head screwdriver to loosen the screws of the battery cover on the bottom surface by rotating them to the arrow mark direction, and detach the battery cover.

② Insert two AA alkaline batteries (sold separately) in the correct orientation.


③ Reattach the battery cover and tighten the screws with a Phillips head screwdriver to the arrow mark direction.



How to use


① Insert the handle along the groove of the Electric Screwdriver main body until a click sound is heard.

② Insert the bit into the Electric Screwdriver main body.




Get ready to play!


① Take the box body out of the package.




② ① Push down the panels.
② Close the lid, like you see in the photo.



③ Rotate and remove the "Support Part" on the rear left and right sides.




④ Go back to the front side, and open the lid 90°. Release the lock, open each panel, and set each part.




How To close the Maintenance Base Box

* Starting from the Tomica Maintenance Base


① Move the "Car wash" to the wall, and place the "Turntable" as shown in the photo. Remove the "Elevator Floor" and "Slope", and set them as per the photo.



② Place the Electric Screwdriver as per the photo, and close the side panels.




③ Close the box by tilting the lid forwards. Close the front panel, and secure the lock.




How to open the Maintenance Base Box

① Open the "Support Part"




② Release the lock, open each panel, and set each part.



Toolbox

Your Toolbox is ready!

Your Maintenance Base is ready!



Observation Floor

Slope

Convex Part

Concave Part

Insert the part of the slope that sticks out into the concave part of the floor.

Vehicle Display Area

Elevator

Set the "Elevator Floor" on the hook.

Rest Area

Maintenance Jack

Car wash


Turntable

The Electric Screwdriver can be rotated in either direction!

When you see this sign, insert the Electric Screwdriver there, and rotate it!

*Tomica (mini car) is not included.

1 Rotate the turntable!



Check your Tomica from all angles, and see if anything broken.

2 Raise the jack and begin maintenance!



Raise the jack, and you can repair the vehicle's undercarriage or change tires.

3 Clean up your Tomica at the car wash!


CAUTION

Some wider vehicles may not be compatible with the car wash. And, if you put narrower vehicles like buses, etc., the sponge roller will not rotate.



Not only cleaning up your Tomica here, you can also apply a coating to its surface.

4 Use the elevator to reach different floors!



You can move to the Rest Area, Observation Floor, or Vehicle Display Area!


*The elevator may not move properly when carrying heavier Tomica.

CAUTION


When the Elevator reaches the top, it will stop when you hear "click click..." sound.



When dropping the elevator, please switch the Electric Screwdriver rotation to the opposite direction.




If you want to change the direction (up or down) when the elevator is moving, switch the Electric Screwdriver rotation to the opposite direction.



How to install the maintenance stand

As the photo shows, slightly expand the jack, and insert the part that sticks out into the hole marked with ○ of maintenance stand.



*Same for the opposite side

*Maintenance, breakdowns, repairs, car-washing, etc., are expressions of imaginary play.